



Notes:

Do not scale or measure off drawing. This is not a true scaled drawing, but an accurate as-built.

Use 2" Square Tubing everywhere except where noted.

Use (4) 6" swivel casters to allow easy rolling of jig and car.

Use boat wench on either end to move car up and down.

Use 3/8" steel wire cable and 3" bearing type pulleys on either end.

Make sure you install some kind of brake system to securely clamp inner frame to upright, when inner frame is up off the ground.

Follow pictures on web site for more detail.

Please contact me at alan_j-a-n-r@ing before to copy and/or distribute any part of this drawing.